



**SPECTRADYNAMICS, INC.**

**LOW NOISE FREQUENCY REFERENCE  
LNFR-100E  
OPERATING MANUAL**

**SPECTRADYNAMICS, INC** • 1849 Cherry St. Unit 2. • Louisville, CO 80027  
Phone: (303) 665-1852 • Fax: (303) 604-6088  
[www.spectradynamics.com](http://www.spectradynamics.com)

## LNFR-100E Description



The LNFR-100E is a high performance 10 MHz distributed frequency reference. It contains a 5 MHz SC-cut ovenized oscillator, a low noise frequency doubler and a distribution amplifier module. The 10 MHz signal is distributed by the distribution amplifier to provide four 10 MHz outputs. Typical cross-channel isolation is 70 dB and reverse isolation is typically greater than 75 dB. The distribution module does not degrade the phase noise performance of the oscillator that is typically  $-142$  dBc/Hz @ Fourier frequency of 10 Hz and  $-168$  dBc/Hz @ Fourier frequency greater than 10 kHz. The LNFR-100E outputs are matched to 50 ohms to obtain better than 25 dB return loss. The LNFR-100E can be phase locked via an electrical tuning port or by providing an external 10 MHz reference.

### Theory of operation

The LNFR-100E contains a 5 MHz SC cut, ovenized oscillator. The output of the oscillator is doubled in frequency and distributed with a high performance distribution amplifier. Four 10 MHz outputs are provided on the back panel. A buffered 10 MHz signal is used internally to phase lock the oscillator to an external 10 MHz input.

## Safety and Preparation for Use



### **CAUTION!**

Voltages capable of causing injury or death are present in this instrument. Use extreme caution whenever the instrument cover is removed.

### **Line Voltage**

This instrument can be setup to operate on 110-120 or 220-240 VAC and a line frequency of 50 to 60 Hz. For conversion to a different line voltage please contact SDI.

### **Fuse**

A 1.0-Ampere 250V slow blow fuse is used in this instrument for 110-120 VAC line voltage. A 0.5-Ampere 250V slow blow fuse is used for 220-240 VAC line voltage. Do not replace with a larger fuse.

### **Line Cord**

The LNFR-100E has a detachable three-wire power cord for connection to a grounded power source. The enclosure of the unit is directly connected to the outlet ground to protect against electrical shock. Always use an outlet with a protective ground and do not disable this safety mechanism.

### **Service**

Do not attempt to service or adjust the instrument unless another person, capable of providing first aid or resuscitation, is present.

### **Operation**

To operate the unit, locate the AC power entry connector on the rear panel and connect the power cable. When power is applied to the unit, a red led located on the front panel labeled "on", should light up.

## The Front Panel



### Power

The LED is on when power is applied to unit and the unit is operating properly.

### External Reference

**Signal** The LED is on when a 10 MHz reference is applied to the tuning port and the reference select switch is in the 10 MHz position.

**DC/10 MHz** Tuning mode select switch used to change from DC tuning mode to 10 MHz external PLL mode.

### 10 MHz Status

**Signal** The LED is on when the internal oscillator is operating properly.

**Locked** The LED is on when the internal 10 MHz oscillator is phase-locked to the external 10 MHz reference. This LED is always off when the instrument is operating in DC tuning mode.

## The Back Panel



---

### External Reference

Tuning      Type N input connector used to supply a 10 MHz reference to the instrument or a +/- 5VDC tuning voltage.

### 10 MHz Outputs

J1 – J4      Type N output connector providing the 10 MHz output signals.

### AC Power Entry Module

The LNFR-100E is factory configured to operate on 110 to 120 VAC.

## Operation



To operate the unit, locate the power entry module on the rear of the enclosure and connect the power cord. Plug the unit into an appropriate power outlet and turn the unit on. A red LED on the front panel labeled "Power" will turn on.

The 10 MHz source requires a one-hour warm up period for the output frequency to stabilize. The frequency of the 10 MHz source can be adjusted through the tuning port on the back panel. The tuning port has two modes of operation, DC tuning and automatic frequency locking. The mode of operation is selected with the tuning select switch. In the DC position a +/- 5VDC signal can be used to adjust the frequency of the LNFR-100E. The tuning port sensitivity is 0.5 Hz/Volt and the frequency modulation bandwidth is approximately 300 Hz. In the 10 MHz position the LNFR-100E will phase-lock to a 10 MHz signal provided at the tuning port. The external reference signal level must be between +7 dBm and +15 dBm for proper operation. The PLL bandwidth has been set to 2 Hz at the factory. For different PLL bandwidth requirements please contact SDI.

## Mechanical Tuning



Mechanical frequency tuning is available to adjust the frequency of the oscillators. **Only fully qualified service personnel should perform this procedure.** Frequency adjustments should be made with the unit having been powered on for at least 1 hour. **Caution must be used to avoid shorting or accidentally touching a line voltage point.**

Before you begin the mechanical tuning adjustment disconnect any signal going to the back panel tuning port. Connect one of the outputs to a frequency counter and make sure that the counter has an accurate frequency reference. The top cover of the LNFR-100E must be removed to perform the mechanical tuning. Locate the 5 MHz oscillator. On the right side panel there is an access hole so that a small flat blade screwdriver can be inserted. Guide the screwdriver from the top and remove the hermetic cover screw to gain access to the tuning screw. Using a tuning tool or small screwdriver adjust the frequency of the 5 MHz oscillator to the desired frequency with the tuning select switch set to the DC position and not having any DC or AC signals on the tuning port. Replace all hermetic covers when done adjusting the frequency of the oscillators. Replace the top cover of the LNFR-100E.

**Note: The LNFR-100E should be turned on for 1 hour prior to any mechanical frequency adjustment.**

# Specifications



## LNFR-100E Specifications

PARAMETER	CONDITIONS	MIN	TYP	MAX	UNITS
Output Level	50 ohm load	+11	+14	+15	dBm
Output Impedance	Return Loss @ 10 MHz		-25		dB
Harmonic Distortion	50 ohm load		-40	-38	dBc
Isolation	output to output	60	70		dB
Temperature Stability	0 - 50 °C		+/- 5x10 <sup>-9</sup>		
Mechanical Tuning			+/- 1x10 <sup>-6</sup>		
Electrical Tuning	+/-5VDC		+/- 2x10 <sup>-7</sup>		
Stability	Allan Variance $\tau=1s$		1E-12		
Phase Noise	1 Hz 10 Hz 100 Hz 1 kHz 10 kHz		-112 -142 -160 -167 -170	-109 -138 -156 -165 -166	dBc/Hz
Spurious		-	-120	-110	dBc

### Absolute Maximum Ratings

RF power on tuning port	+20dBm Maximum
DC Voltage on tuning port	+/-10 VDC Maximum
RF Power on outputs	+20dBm Maximum
DC Voltage on outputs	50 VDC Maximum
Storage Temperature	-10 to +75 °C
Operation Environment	0 to +50 °C

**Chassis**     2U H, 19 " W, 16" D

## Warranty



The LNFR-100E is warranted to be free of defects under normal operating conditions, as specified, for one year from date of original shipment from SpectraDynamics, Inc (SDI). SDI's obligation and liability under this warranty is expressly limited to repairing or replacing, at SDI's option, any product not meeting the said specifications. This warranty shall be in effect for one (1) year from the date an LNFR-100E is sold by SDI. SDI makes no other warranty, express or implied, and makes no warranty of the fitness for any particular purpose. SDI's obligation under this warranty shall not include any transportation charges or costs of installation or any liability for direct, indirect, or consequential damages or delay. Any improper use, operation beyond capacity, substitution of parts not approved by SDI, or any alteration or repair by others in such manner as in SDI's reasonable judgement affects the product materially and adversely shall void this warranty. No employee or representative of SDI is authorized to change this warranty in any way or grant any other warranty.